

POWERFLEX®

PART NUMBER

PFR57-714

DESCRIPTION

REAR ANTI ROLL BAR TO LINK ROD BUSH

INSTALLATION GUIDE

Contents (parts per pack):

- 4 x Polyurethane Bushes
- 1 x PTFE/Silicone Grease
- 4 x Stainless Steel Sleeves
- 2 x Mild Steel M10 Washers

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.



Fitting Instructions:

1. Remove the anti roll bar link rod from the vehicle.
2. Remove the original rubber bushes from the link rod, as shown in Figure 1.
2. Clean out any dirt and corrosion from the inside surface of the link rod bores and file off any sharp edges.
3. Fit the new polyurethane bushes into the bores, as shown in Figure 2.
4. Apply some of the supplied grease into the inner surface of the bush and insert the stainless steel sleeves into the bores of the bush.
5. Use the supplied washers while fitting the original bolts and nuts, as shown in Figure 3.

Note: Fit the washers from the inside of the link rods.

6. Refit the link rod back to the vehicle and tension all hardware to manufacturers recommended torque settings.

