

POWERFLEX®

PART NUMBER

PF17-402

DESCRIPTION

Lower Wishbone Bush

INSTALLATION GUIDE

Contents (parts per pack):

4 x Polyurethane Bushes	4 x Zinc Plated Mild Outer Shell
4 x Smaller Steel Washer	4 x Larger Steel Washer
4 x Stainless Steel Sleeve	1 x PTFE/Silicone Grease

Please read the complete fitting instructions and check package components before fitment. These fitting instructions are to be used as a guide and in conjunction with workshop manual.

It is recommended that:

- all work to be carried out by a licensed technician;
- all safety precautions adhered to;
- wheel alignment to be checked and adjusted as required after any suspension work.
- All fasteners must be tensioned to manufacturer's torque settings.

Fitting Instructions:

1. Remove the original bushes from the arm.
2. Clean any dirt and corrosion from the hole in the arm and file off any sharp edges.
3. Press the mild steel outer shells so that the larger face is facing the rear of vehicle. This is shown in Figure 2.
4. Press the Powerflex bushes into the outer shells in the orientation shown in figure 1.
5. Apply a small amount of grease to the bore of the bush and then press the steel sleeves into the bushes. The sleeves should protrude from the bushes a small amount. This is to accommodate the washers.
6. Apply a small amount of grease to the upper and lower face of the bushes and then place the larger washer on the top face of the bush and smaller washer on the lower face, as shown in figure 1.
7. Refit the arm to the car and tension all hardware to manufacturers recommended torque settings.



Figure 2



Front of Car



Figure 2

